

Technical Rider

Classic Seger (Bob Seger Tribute)

Contact: Darren McLeay - 519-333-9532 or info@classicseger.com

- All member of the band will wear their own IEM – NO STAGE		Input List	
MONITORS REQ'D (We bring our own self-contained IEM	Channel	Source	
Setup, including 24ch mixer and 20ch split snake. The 20ch	1	Kick	
split will be provided to FOH)	2	Snare	
- All members PROVIDE THEIR OWN MICS, STANDS AND	3	Tom1	
CABLES.	4	Tom2	
- Drummer brings a full kit and uses 6ch – Kick, snare, Tom1,	5	OH-L	
Tom2, OH-L, OH-R (ch1-6)	6	OH-R	
- Lead Singer vocal mic plus an acoustic guitar – each on a	7	AccGtr1	
single mono channel (ch14-Vocal and ch7-Acoustic)		Acc/Elec	
- One Bk up Singer plays an acoustic guitar and an Electric	8	Gtr	
Guitar using a single mono channel (ch 8)	9	Bass	
- Bass player uses an on-stage bass rig with single mono	10	Lead Guitar	
output (ch 9)	10	Sax	
- Lead Guitar player uses a pedal board with a single mono	12	B3	
output (ch 10)	13	Piano	
- Sax player uses a stand-mounted mic plus a wireless for	14	Lead Voc	
one sax – submixed to single channel (ch 11)	15	BU Voc	
- B3 is a Nord using a single mono output (ch 12)	16	BU Voc	
- Piano is a Yamaha CP73 kybd using a single mono output	17	BU Voc	
(ch 13)	18	BU Voc	
- Bk Up Singers (stage right) use vocal mics (ch 15&16)	19	n/a	
- NOTE: one BU singer *may* use 2 mic positions summed to	20	n/a	
single channel			
- Piano and B3 use bk/up vocal mics (ch 17&18)			
- Floor Toms (stage right) need to be mic'd for FOH and are			
not included in the IEM monitor system			
Staging:			
- Where available, we will require a full riser for the Drums			
and 2 side risers for BUVoc and B3 (see Stage Plot)			